

# Correct change of the Barefoot front pommel



## ! Important:

Please never place saddle flat on the ground to change pommel inserts. To stabilize whilst replacing inserts, place saddle on saddle rack or something similar like over the back of a sofa or chair.



- Step 1** ① Fold velcroed seat forward over the pommel.
- Step 2** ② Open zip of pommel pocket and widen it a little.
- Step 3** ③ Now slowly loosen insert from pocket starting on one side then moving to the other until insert pops out easily.
- Step 4** ④ Again gently insert new pommel bit by bit into one side of the pocket first. Pay attention to the direction of the insert. Sticker ‚R‘ for right and ‚L‘ for left.
- Step 5** ⑤ Then insert other half of pommel into pocket. The new pommel insert has to be fully and deeply inserted into both sides of the pocket.
- Step 6** ⑥ If pommel has been inserted correctly, zip can easily be pulled together with both hands. This is the only way to ensure that zip can then be easily and completely fastened.
- Step 7** ⑦ Zip can now easily be closed. If this is not the case, pommel has not been inserted correctly and has to be pushed in deeper.